

Exxo Play Ball — 20" & 40" Sets

(Kids • Dogs • Horses)

What's in the box

- 1 heavy-duty fabric ball cover
- 1 anti-burst PVC ball (either 20" or 40" depending on your purchase)
- 1 pump
- 2 valve plugs
- 1 plug-puller tool

Note: Fold marks on the PVC ball are normal and will relax after inflation.

Before you begin

- Use in a large, open area clear of traffic, fences, sharp objects, and hazards.
- Let the PVC ball come to room temperature if it feels hot or cold.
- The ideal inflated diameter is 20" or 40" depending on your purchase. Do not over-inflate.

Inflate & assemble

1. Remove the PVC ball from its packaging and lay it flat with the inflation hole facing up.
2. Slide the PVC ball into the fabric cover, aligning the ball's inflation hole with the cover opening.
3. Begin inflating using the included pump (or a compatible electric pump).
4. Continue inflating until the ball fills the cover snugly and reaches 20" or 40" in diameter.
5. Quickly insert a valve plug to seal. If needed, remove the plug and add a little air to fine-tune the fit.
6. Keep the spare plug and plug-puller in a safe place.

Warning: If using an electric pump, watch the size continuously to avoid over-inflation and cover damage.

Safe play guidelines

For Kids

- Adult supervision required at all times. Recommended for children 3+.
- Play next to or with the ball (pushing, rolling, gentle kicking). Do not sit, stand, or jump on the ball.
- Wear closed-toe shoes; keep clear of faces and fragile items.
- Use on grass or a smooth surface away from streets, driveways, stairs, pools, or steep slopes.

For Dogs

- Introduce the ball gradually. Start with gentle rolling and reward curiosity.
- This is a herding/chasers' play ball—made to push, nose, and chase, not to chew.
- Supervise play; remove the ball if the cover or valve area is being chewed.
- Trim nails as needed to help the cover last longer.

For Horses

- Introduce by rolling the ball while walking away to encourage following.
- When comfortable, bounce the ball near the horse and walk briskly while kicking so the horse tracks it.
- Allow the horse to nudge, push, and herd the ball; avoid forcing interaction.

Care & maintenance

- Wipe the cover with a damp cloth and mild soap; air-dry fully before storage.
- Normal use may require occasional top-ups of air.
- Store clean and dry, out of direct sun and heat. Avoid sharp objects and rough or abrasive surfaces.

Important warnings

- Not a flotation device, safety device, or seat.
- Do not over-inflate beyond 20" or 40" depending on your purchase.
- Keep away from fire, heaters, and extreme temperatures.
- Inspect before each use. Stop use if the cover or ball is damaged.