


# HOW TO USE?



## SET UP



1. Take the tent out of the bag




2. Fold out the bottom part



3. Pull out the upper part


4.



## TAKE DOWN



Step 01

Unlock the top of the tent




Step 02

Pull out here




Step 03

Fold the tent



Step 04

Place the tent in the bag



### Material

50% fibreglass rod  
50% Polyester

### WARNING

- Set-up and breakdown by an adult required.
- Wipe with a damp cloth.
- Keep away from fire.